


COFFEE FORMAT®

www.coffeeformat.pl


Instrukcja obsługi
User Manual



Automatyczny Cleaner do kolby


Automatic Portafilter Cleaner (PC)

OPIS CZĘŚCI




PARAMETRY

← -- 141~168mm -- →



← -- 141~168mm -- →



Nazwa produktu

Automatyczny Cleaner do kolby

Model

PC

Wymiary (S*G*W)

141 x 141 x 230mm

Napięcie zasilające

AC100~240V 50/60Hz

Moc

36W

Waga

2kg

USTAWIENIA I KONFIGURACJA

Automatyczny Cleaner do kolby może być umieszczony na stole roboczym, jest również kompatybilny z dedykowanym pojemnikiem na fusy.

Jeśli zewnętrzna średnica Cleanera nie może zostać dopasowana do odpowiedniego rozmiaru, nie można go umieścić w pojemniku na fusy.

Proszę uważnie przeczytać poniższe kroki regulacji:


1. Zainstaluj Cleaner do kolby w stole roboczym
 - 1.1 Wywierć otwór w stole roboczym – średnica otworu powinna wynosić 120mm;
 - 1.2 Zdejmij trzy „uchwyty” z Cleanera i zainstaluj go na stole;
 - 1.3 Ustal pozycję otworu pozycjonującego Cleanera względem jego krawędzi;
 - 1.4 Wykonaj od 1 do 3 otworów pomocniczych o średnicy 6mm w stole;
 - 1.5 Przymocuj Cleaner do stołu roboczego;
 - 1.6 Podłącz zasilanie do Cleanera.



Zdejmij uchwyty.




Wywierć otwory (duży otwór: 120mm, mały otwór: 6mm)



Umieść Cleaner w otworze i zamocuj go w stole roboczym.

2. Zainstaluj Cleaner do kolby w pojemniku na fusy
- 2.1 Dostosuj zewnętrzną średnicę Cleanera do średnicy pojemnika na fusy;
- 2.2 Umieść Cleaner w pojemniku na fusy;
- 2.3 Podłącz zasilanie do Cleanera.



Poluzuj trzy śruby i dopasuj uchwyty do korpusu urządzenia.



Umieść urządzenie czyszczące w pojemniku na fusy.

WARUNKI UŻYTKOWANIA

Proszę umieścić Automatyczny Cleaner do kolby (pojemnik na fusy) na równej, niepodatnej na wibracje powierzchni, aby podczas użytkowania nie dochodziło do jego drgań, co mogłoby uszkodzić urządzenie lub skrócić jego żywotność.

KONTROLA PRZED UŻYCIEM

1. Sprawdź przewód zasilający oraz wtyczki, aby upewnić się, że nie ma oznak uszkodzenia.
2. Włóż przewód zasilacza do tylnej części Automatycznego Cleanera, a następnie podłącz go do gniazda zasilającego.

REGULACJA GŁOWICY SZCZOTKI

Automatyczny Cleaner do kolby może być używany do czyszczenia sitka na podwójne espresso o średnicy od 53mm do 58,5mm.

Domyślna głowica szczotkująca jest odpowiednia dla sitka o średnicy 58mm, którego wewnętrzna ścianka jest pionowa (patrz lewy obrazek poniżej).


Jeśli wewnątrz sitka nie jest pionowe (patrz prawy obrazek poniżej) i dno sitka ma pewne nachylenie, głowicę szczotkującą można dostosować, przycinając silikonowe włosie szczotki zgodnie z kątem nachylenia.




pionowa ścianka wewnętrzna




nachylenie do wewnątrz



Odetnij nadmiar silikonowej szczoteczki zgodnie z linią odniesienia i upewnij się, że górna część głowicy szczotkującej jest mniejsza niż wewnętrzna średnica dna koszyka.



Silikonowa szczotka może dotrzeć do pionowej ścianki wewnętrznej koszyka.



Silikonową szczotkę należy przyciąć, aby mogła dotrzeć do koszyka o nachyleniu do wewnątrz.

Uwaga: Jeśli używasz sitka o średnicy 54mm, należy przyciąć silikonową szczotkę zgodnie z powyższym opisem.

INSTRUKCJA OBSŁUGI

1. Umieść kolbę na szczotce i dociśnij w dół.
2. Czyść przez 2–3 sekundy, następnie unieś kolbę nad głowicę szczotki.
3. Ponownie dociśnij kolbę w dół, aby kontynuować czyszczenie.

CZYSZCZENIE

Jeśli na głowicy szczotki znajduje się dużo zmielonej kawy, można ją wyjąć i umyć wodą. Jeśli duża ilość zmielonej kawy znajduje się na wewnętrznych ściankach Cleanera, można je również wyczyścić za pomocą szczotki.

KONSERWACJA

W razie potrzeby skorzystania z serwisu posprzedażowego należy wyłączyć zasilanie, oczyścić urządzenie i skontaktować się z miejscem zakupu.



Nie próbuj naprawiać urządzenia samodzielnie w przypadku usterki elektrycznej.

W razie potrzeby dokupienia części skontaktuj się ze sprzedającym urządzenie.

WARUNKI GWARANCJI


1. Warunki gwarancji nie obejmują uszkodzeń spowodowanych niewłaściwą instalacją, nieprawidłowym użytkowaniem, nieodpowiednim czyszczeniem i konserwacją.
2. Gwarancja nie obejmuje uszkodzeń wynikających z używania nieoryginalnych części zamiennych.
3. Gwarancja nie pokrywa kosztów ogólnej konserwacji ani kosztów robocizny związanych z wymianą części zamiennych.

DESCRIPTION OF PARTS




PARAMETERS

← -- 141~168mm -- →



← -- 141~168mm -- →

↑
230mm
↓



Product Name

Automatic Portafilter Cleaner

Model

PC

Size (L*W*H)

141 x 141 x 230mm

Voltage

AC100~240V 50/60Hz

Power

36W

Weight

2kg

SET-UP AND BASIC ADJUSTMENT

Automatic Portafilter Cleaner can be placed on the worktable and it is also compatible with the knock tubes. If the outer diameter of the cleaner cannot be adjusted to a suitable size, it cannot be placed in the knock tube.

Please read the following adjustment steps carefully:


1. Install the Portafilter Cleaner in the worktable
 - 1.1 Drill a hole in the worktable, the diameter of the hole is 120mm;
 - 1.2 Remove the three "wings" of the Cleaner and install it on the table;
 - 1.3 Determine the position of the positioning hole of the Cleaner through the edge of the Cleaner;
 - 1.4 Open 1-3 6mm holes on the table;
 - 1.5 Fix the Cleaner on the worktable;



Remove the Wings.



Drill the Holes (Big Hole: 120mm, Small Hole: 6mm).




Put the Automatic Portafilter Cleaner into the hole and fix it on the worktable.

2. Install the Automatic Portafilter Cleaner into the knock tube

2.1 Adjust the outer diameter of the cleaner according to the knock tube diameter;

2.2 Put the Cleaner into the knock tube;

2.3 Connect the power to the Cleaner;



Loosen the three screws and adjust the wings to fit the knock tube.



Place the Automatic Portafilter Cleaner on top of the knock tube.

USE ENVIRONMENT

Please place the Automatic Portafilter Cleaner (knock tube) on a level, non-vibrating surface, so as not to shake the Cleaner (knock tube) during use, damage the Cleaner or reduce the service life of the Cleaner.

INSPECTION BEFORE USE

1. Inspect the power cord to ensure there are no signs of damage or poor connection fittings.
2. Insert the power adaptor cord into the rear of the Automatic Cleaner, then plug it into the power socket.

UPDATE THE BRUSH HEAD

Automatic Portafilter Cleaner can be used to clean the Double Shots Basket from 53mm to 58.5mm.


The default brush head is suitable for the 58mm basket, and its inner wall is required to be vertical (below left picture); If the inside of the basket is not vertical (below right picture), and there is a certain slope at the bottom of the basket, the brush head can be modified according to the slope on the silicone brush head;




Inner wall vertical




Inward inclination



Cut off the excess part according to the reference line, and make sure the silicone top of the brush head is smaller than the inner diameter of the bottom of the basket.



The silicon brush can access to the inner wall vertical basket.



The silicon brush need to be cut to access to the inward inclination basket.

Notice: If you are using 54mm basket, you need cut the silicon brush according to the upper description.

OPERATION

1. Put the portafilter on top of the brush and press down.
2. Clean for 2~3 seconds, lift the portafilter over the top of the brush head.
3. Press the portafilter down again to clean.

CLEAN

If there is a lot of ground coffee on the brush head, you can take out the brush head and clean it with water; if there is a lot of ground coffee on the inner wall of the cleaner, you can also use a brush to clean it;

SERVICE

When or if you require after-sales service, please turn the power off, clean the machine, and call your place of purchase.

Do not attempt to repair it yourself in case of electrical fault.

If you require replacement parts, please contact the device supplier.

WARRANTY CONDITIONS

1. The warranty conditions do not cover damages caused by incorrect installation improper use, improper cleaning and maintenance.
2. Warranty does not cover damage caused from using non-genuine replacement parts.
3. Warranty does not cover general maintenance and or labor costs associated with replacement spare parts.

MADE IN CHINA

**Manufactured for/
Wyprodukowano dla:**

Aqua Solution Sp. z o.o.

Piekary 371

32-060 Piekary | Poland

biuro@aquasolution.pl

12 201 86 96

COFFEE FORMAT

®

www.coffeeformat.pl